

These instructions should be read thoroughly before installing.
This is a guide to assist in the installation of your Roller Blinds

You will need the following tools

- Cordless drill with Phillips head drill bit
- Metal tape measure
- Ladder (if required)
- Spirit level

Parts supplied:

- 1 x blind
- 2 brackets + screws
- 1 Child Safety chain guide with screws and anchors

Standard Roller Blind bracket



Child Safety cord guide 5mm red plugs 38mm x 8g dome head screws



Roller Blind spring pin end



What are you mounting your blind to ?

Mount the blind to	How to prepare
Timber	Pre-drill holes and use the provided screws
Plaster	We recommend use of the Ramset 10mm Grip Hollow Wall Anchor
Concrete / Stone / Brick / Tile	Use a Masonry drill and appropriate plugs, anchors or screws

Installation Steps:

1. Mark the drill point for the screw holes through the brackets, using the marks to align.
2. Once the holes are drilled, mount the brackets.
3. Check which side the control is on before proceeding. Lift the Roller Blind up and insert the idle end pin into the hole in the idle end bracket.
4. Supporting the blind, push towards the idle pin end so that the spring pin retracts in, allowing the lugs on the chain drive end to be aligned with the slots in the chain drive bracket.
5. If aligned correctly, the blind should drop into place in the brackets and the spring pin end will take up the tension and secure the locating points.
6. Release the operating chain from the packed position and make sure it is free from any tangles and knots.
7. Check operation of Roller Blind by fully rolling down the blind (the tube of the blind will be seen).
8. Roll the blind fully up, checking the blind is tracking correctly. Note: If the fabric is tracking either side of the tube and the blind has been installed level. The blind must be fully rolled down again and masking tape strips approximately 50mm long must be placed on the face of the tube. The masking tape strips must be attached the opposite side that the fabric is tracking too. Start with using three masking tape strips on top of each other.
9. Check operation of blind again and add or remove masking tape strips until blind is tracking straight.

IMPORTANT

Child Safety Device

Please note that **Australian Child Safety Laws** state that a cord tensioner must be installed if the chain is less than 1.6m from the floor to prevent any risk of strangulation.

- Correctly position the Child Safety cord guide by ensuring that the chain is in a straight line down from the control mechanism.
- Pull the chain guide down then back it off by 5mm, mark the location through the mounting holes.
- Pilot drill a small hole in these marked points, then securely mount the chain guide.
- Use the screws provided to secure the device.