

These instructions should be read thoroughly before installing.  
This is a guide to assist in the installation of your Roman Blinds

## You will need the following tools

- Cordless drill with Phillips head drill bit
- Metal tape measure
- Ladder (if required)
- Spirit level

## Parts supplied:

- 1 x blind
- 2 brackets + screws
- 1 Child Safety cord guide or 2 cleats with screws and anchors



## What are you mounting your blind to ?

Mount the blind to	How to prepare
Timber	Pre-drill holes and use the provided screws
Plaster	We recommend use of the Ramset 10mm Grip Hollow Wall Anchor
Concrete / Stone / Brick / Tile	Use a Masonry drill and appropriate plugs, anchors or screws

## Installation Steps:

1. Hold the headbox up to the Reveal or Face Fit window frame. Using a pencil, create a small mark to show the position of both ends, ensuring the headbox is centred and level.
2. Using the tape measure, confirm the blind is centred and make two new marks 50mm in from the end outside marks. This will be the mounting bracket location. (Evenly space additional brackets if supplied)
3. Check that the marks made for the brackets are perfectly level (it is crucial that the blind is mounted level in order to operate correctly).
4. Once the holes are drilled, mount the brackets.

Note: Before attempting to install the blind into the brackets, make sure that the lifting cords are removed from their packed position and make sure there are no tangles or knots.

5. Lift the headbox up into the installation bracket and clip the front of the headbox onto the bracket. Push the back of the headbox up into the bracket so it locks into place.
6. Lower the blind by using the cord and check operation.

### IMPORTANT

#### Child Safety Device

Please note that **Australia Child Safety Laws** state that a cord tensioner must be installed if the chain is less than 1.6m from the floor to prevent any risk of strangulation.

- Correctly position the Child Safety cord guide or cleat by ensuring that the chain or cord is in a straight line down from the control mechanism.
- Pull the chain guide down then back it off by 5mm (or position the cleats), mark the location through the mounting holes.
- Pilot drill a small hole in these marked points, then securely mount the Child safety device.
- Use the screws provided to secure the device.