

These instructions should be read thoroughly before installing. This is a guide to assist in the installation of your Vertical blind.

You will need the following tools

- Cordless drill with Phillips head drill bit
- Metal tape measure
- Ladder (if required)
- Spirit level

Parts supplied:

- 1 x blind
- 2 brackets + screws
- 1 Child Safety device with screws and anchors



What are you mounting your blind to ?

Mount the blind to	How to prepare
Timber	Pre-drill holes and use the provided screws
Plaster	We recommend use of the Ramset 10mm Grip Hollow Wall Anchor
Concrete / Stone / Brick / Tile	Use a Masonry drill and appropriate plugs, anchors or screws

Installation Steps:

1. Hold the track up to the reveal or face of the window frame. Using a pencil create a small mark to show the position of both ends, ensuring the track is centred and level.
2. Using the tape measure, confirm the blind is centred and make two new marks 150mm in from the end outside marks. This will be the mounting bracket location. (Evenly space additional brackets where supplied)
3. Check the marks are level. (It is crucial that the blind is mounted level to operate correctly)
4. Mark the drill point for the screw holes through the brackets, using the marks to align.
5. Once the holes are drilled, mount the brackets.
6. Check which side the control is on before proceeding. Hold the track up to the brackets ensuring the front lip of the track engages into the lip of the bracket, twist up and backwards to snap the track into the bracket. N.B. For face fit brackets, tighten the screw at the front once the track is inserted.
7. Release the operating chain from the packed position and make sure it is free from any tangles and knots.
8. Correctly position the chain guide by ensuring that the chain and cord is in a straight line down from the control mechanism
9. If the cord and chain are different lengths, put the cord on the bottom hook and the chain on the top hook, cut the chain to the correct length by removing the metal joiner. Fasten child safety device to wall (instructions below)
10. With the track in the stacked position, ensure the slat carrier hooks are in an open position. Take one slat at a time and attach to the carrier hook.
11. Check slats rotate 180 degrees and are free from obstructions.

IMPORTANT

Child Safety Device

Please note that **Australian Child Safety Laws** state that a cord tensioner must be installed if the chain is less than 1.6m from the floor to prevent any risk of strangulation.

- Correctly position the Child Safety cord guide by ensuring that the cord and chain are in a straight line down from the control mechanism.
- Pull the chain guide down then back it off by 5mm, mark the location through the mounting holes.
- Pilot drill a small hole in these marked points, then securely mount the chain guide.
- Use the screws provided to secure the device.